HiCAMS User Guide

Chapter 2: Contract Maintenance

Section 4A: Working with Warranties

<u>Contents</u> About Warranties Entering a Line Item Warranty

Revision History

Comments or concerns with this document should be directed to the NCDOT Construction Unit at 919-707-2400.

Date	Version	Description	Author
December 1997	1.0	Initial Version	HiCAMS Documentation Specialist
November 2002	2.0	Updated Document	Deirdre Warner
December 2010	3.0	Revised format and added business information	Marie Novello
December 2011	3.1	Updated phone number	Marie Novello
May 2012	3.2	Renumbered User Guide and reordered content	Marie Novello
October 2013	3.3	Renumbered to match HiCAMS menu	Marie Novello

About Warranties

Warranties in HiCAMS can be set at both the Contract level and the Line item level.

Overall Contract Warranties based on Contract Special Provision SP1G145 "Twelve Month Guarantee" are tracked using the Project Guarantee fields located on the Review Contract Details > General Tab. This warranty can also be indicated during Contract Activation by clicking on the Project Guarantee checkbox.

Contract Warranties at the Line Item level are tracked using the Warranties button. This button is available during Contract Activation, and throughout the life of the contract. If a warranty is established on a line item after the contract has been activated, the button can be accessed from either the Review Contract Details > General Tab or the View Line Item Details window.

Until recently, Pavement Markings had a 180-day observation period that was tracked at the Line Item level. Per Ron Hancock's Memorandum dated 6 August, 2010, Pavement Markings now have a twelve month observation period and are tracked as part of the Twelve Month Guarantee.

The Line Item level warranty is currently used to track the Partial Acceptance twelve month review for Deck and Rail, and any other items that may be specified in the contract.

For additional information on Warranties, please contact the Construction Unit.

Entering a Line Item Warranty

The Warranties button can be accessed in either the Review Contract Details window or the View Line Item Details. The process is the same regardless of which window is used.

To work with Warranties, go to Functions > Contract Maintenance > Review Contract Details or Functions > Contract Maintenance > View Line Item Details.

Step 1: Enter the Contract Number whose Warranties you wish to enter in the Contract field.

Note: For information on ways to enter your contract number, see the User Guide "Getting Started" in the User Guides section of the HiCAMS home page.

Below is an example of the Contract Details window showing the Warranty button. Notice also that the Project Guarantee checkbox is checked.

Contra	contract Det	tails (C2012 252	52) 101 Co	ntracto	: SANFI	ORD CONTRA	CTORS	. INC		Statu	s: Accepted			-
— Descri	iption (ni	ckname)	NC 41	South R	ver Bric	ige								
ieneral	Routes/C	Counties	Staff	Goals	Dates	Financials	Status	Co	mpletion	CCU Log	M&T Status Histo	у		
Ni	ckname:	NC 41 Sc	uth Rive	er Bridge					Bid A	.mount: \$1,	981,901.27			
L	ocation:	BRIDGE	OVER S	OUTH RI	VER & /	APPORACHES	S ON	2	Contra	t Type: Ot	ner 🔄	·		
Cor	ntractor:	NC-41. 3100 -	SANEO	RD CON	TRACT	ORS. INC.		81		WBS: 331	164.3.1			
Fiscal V	endor #:	22479						<u>685</u>	Spe	c Year: 200	06			
Physi	ical Len:	0.341 Mil	es - Eng	lish					W	ork Order	Federal Aid Numbe	r Merge	TIP	
C	omment:							2	331	64.3.1	BRSTP-41(25)	N	B-3613	
Proj	ect Guara Guar risions Fu	ch Incent antee rantee: R ulfilled: 0	cive Z [0/00/000	12 Mc	onths	Slanket Cons Mainframe Co Expires: 1	ent	1	, I Nei	gional Cate	gory: Regional]		Þ
	<u> </u>	Ву:					/] <u>€</u>						

Step 2: At the bottom of the window, click on the Warranties button. The Set Warranties window opens.

Descrip	tion (ni	ickname): NC 41 South River Bridge					
ne Item	Cont Adj	Description	иом	Warranty Start Date	Warranty Stop Date	Number of Days	-
1		MOBILIZATION	LS	00/00/0000	00/00/0000		
2		REINF BRG APPR ********** [(21+59	.9 LS	00/00/0000	00/00/0000	▲ ▼	
3		GRADING	LS	00/00/0000	00/00/0000	<u> </u>	
4		SUPP CLEARING & GRUBBING	ACR	00/00/0000	00/00/0000		
5		UNDERCUT EXCAVATION	CY	00/00/0000	00/00/0000		
6		DRAINAGE DITCH EXCAVATION	CY	00/00/0000	00/00/0000		
7		SELECT GRANULAR MATERIAL	CY	00/00/0000	00/00/0000		
8		SOIL STABILIZATION FABRIC	SY	00/00/0000	00/00/0000		
9		FND CONDIT MATL MINOR STRS	TON	00/00/0000	00/00/0000		
10		15" RC PIPE CULV III	LF	00/00/0000	00/00/0000		
11		15" BCCSP B 0.064"	LF	00/00/0000	00/00/0000		
12		PIPE REMOVAL	LF	00/00/0000	00/00/0000		
13		AGGREGATE BASE COURSE	TON	00/00/0000	00/00/0000		
			,			_	_

Below is an example of the Set Warranties window.

- **Step 3:** Select the line item for which you wish to set a Line Item level Warranty.
- Step 4: Enter the Line Item's Warranty Start Date. The date can be keyed into the field (use the MM/DD/YYYY format), or the calendar function can be accessed by double clicking in the date field and selecting the Start Date from the calendar.
- **Step 5:** Next enter <u>either</u> the Warranty End Date or the Number of Days. HiCAMS will calculate the other entry automatically.
- **Step 6:** Save the record. A completed Line Item Warranty entry is shown on the next page.

Descrip	otion (ni	ckname): NC 41 South River Bridge				·	
ne Item	Cont Adj	Description	иом	Warranty Start Date	Warranty Stop Date	Number of Days	^
81		HP12X53 PILES	LF	00/00/0000	00/00/0000		
82		PP18X0.50 GALV STL PILE	LF	00/00/0000	00/00/0000		
83		PILE REDRIVES	EA	00/00/0000	00/00/0000		
84		CONCRETE BARRIER RAIL	LF	09/10/2010	09/09/2011	365 🍦	
85		RIP RAP II (2'-0")	TON	00/00/0000	00/00/0000		
86		FILTER FABRIC FOR DRAINAGE	SY	00/00/0000	00/00/0000		
87		ELASTOMERIC BEARINGS	LS	00/00/0000	00/00/0000		
88		3'-0"X 2'-3" PRESTR BOX BEAM	LF [00/00/0000	00/00/0000		
89	SA1	GDRL ANCH UNITS Type B-77 TEMP	EA	00/00/0000	00/00/0000		
90	SA2	EVAZOTE JOINT SEALS	LS	00/00/0000	00/00/0000		
91	SA3	Milling Asphalt Pavement 0"-10"	SY	00/00/0000	00/00/0000		
92	SA3	Traffic Bearing Drop Inlets	EA	00/00/0000	00/00/0000		
93	SA4	Turbidity Curtain	LS	00/00/0000	00/00/0000		
					1	_	•

Once the Date has been entered, close the window. HiCAMS will automatically send a notification to the Resident Engineer and Project Engineer of record four (4) weeks and two (2) weeks before the Warranty expires as a reminder to re-inspect the work. A notification will also be sent when the Warranty expires.