DocuSign Envelope ID: 7013626D-DE5C-4780-B3FF-796E39060156

PROJECT REFERENCE NO.	SHEET NO.
R-5816	Sig. 1.4

OVERLAP "F"

OUTPUT ASSIGNMENT PROGRAMMING DETAIL

(program controller as shown below)

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT (ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE + KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 22, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

```
PAGE:1  C1 PIN:24   VEHICLE PHASE
OUTPUT ASSIGNMENT #................22
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

SCROLL DOWN TO VIEW ALL DATA

THIS ENTRY IS EXISTING BY DEFAULT

```
PAGE:1  C1 PIN:24   VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...6
SELECT COLOR (0=RED,1=YEL,2=GRN).....0
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:24   VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................22
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

PRESS "+" KEY FOR OUTPUT 23

```
PAGE:1  C1 PIN:25  VEHICLE PHASE
OUTPUT ASSIGNMENT #................23
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

SCROLL DOWN TO VIEW ALL DATA

THIS ENTRY IS EXISTING BY DEFAULT

```
PAGE:1  C1 PIN:25   VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...6
SELECT COLOR (0=RED,1=YEL,2=GRN).....1
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:25    VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................23
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

PRESS "+" KEY FOR OUTPUT 24

```
PAGE:1  C1 PIN:26  VEHICLE PHASE
OUTPUT ASSIGNMENT #................24
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

SCROLL DOWN TO VIEW ALL DATA

THIS ENTRY IS EXISTING BY DEFAULT

```
PAGE:1  C1 PIN:26   VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...6
SELECT COLOR (0=RED,1=YEL,2=GRN).....2
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:26  VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................24
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

Electrical Detail - Sheet 3 of 3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 02-0256
DESIGNED: July 2022
SEALED: 7/26/2022
REVISED:

Project #: 38564.16

VHB Engineering NC, P.C. (C-3705)
940 Main Campus Drive, Suite 500
Raleigh, NC 27606
919.829.0328

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Transportation Mobility and Safety Division
Department of North Carolina Department of Transportation
Signal Design Section
750 N.Greenfield Pkwy,Garner,NC 27529

NC 58 (Fort Macon Road)
at
SR 1182 (Atlantic Beach Cswy)

Division 2 Carteret County Atlantic Beach

PLAN DATE: July 2022	REVIEWED BY:
PREPARED BY: J. Townsend	REVIEWED BY:

REVISIONS	INIT.	DATE

SEAL

NORTH CAROLINA PROFESSIONAL SEAL 031533 ENGINEER JOHN G. TOWNSEND
7/26/2022

SIGNATURE DATE

SIG. INVENTORY NO. 02-0256

7/26/2022
R:\Carteret Co\Signals\Design\Signals\M20025611_sm_ele.dgn
User:jtownsend