PROJECT REFERENCE NO.	SHEET NO.
U-5518EM	Sig. 1.3

"PHASE 5" to OVERLAP "C"
OUTPUT ASSIGNMENT PROGRAMMING DETAIL

(program controller as shown below)

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT (ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE + KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 30, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

SCROLL DOWN TO VIEW ALL DATA

```
PAGE:1  C1 PIN:32  VEHICLE PHASE
OUTPUT ASSIGNMENT #................30
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

EXISTING DEFAULT ENTRY

```
PAGE:1  C1 PIN:32  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...3
SELECT COLOR (0=RED,1=YEL,2=GRN).....0
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:32   VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................30
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

VEHICLE OVERLAP C (RED) LOAD SWITCH S5

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT (ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE + KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 32, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

SCROLL DOWN TO VIEW ALL DATA

```
PAGE:1  C1 PIN:34   VEHICLE PHASE
OUTPUT ASSIGNMENT #................32
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

EXISTING DEFAULT ENTRY

```
PAGE:1  C1 PIN:34  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...3
SELECT COLOR (0=RED,1=YEL,2=GRN).....2
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:34  VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................32
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

VEHICLE OVERLAP C (GREEN) LOAD SWITCH S5

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT (ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE + KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 31, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

SCROLL DOWN TO VIEW ALL DATA

```
PAGE:1  C1 PIN:33  VEHICLE PHASE
OUTPUT ASSIGNMENT #................31
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

EXISTING DEFAULT ENTRY

```
PAGE:1  C1 PIN:33  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...3
SELECT COLOR (0=RED,1=YEL,2=GRN).....1
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:33  VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................31
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

VEHICLE OVERLAP C (YELLOW) LOAD SWITCH S5

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 05-0740
DESIGNED: August 2014
SEALED: 8/28/2014
REVISED: N/A

THIS ELECTRICAL DETAIL SUPERSEDES THE DETAIL SEALED ON 04/30/14

Electrical Detail - Sheet 3 of 3

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:

Transportation Mobility and Safety Division
STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
Signal Management Section

750 N.Greenfield Pkwy,Garner,NC 27529

NC 97
at
SR 2329 (Marshburn Road/
Lizard Lick Road)

Division 5 | Wake County | Lizard Lick

PLAN DATE:	August 2014	REVIEWED BY:	T. Joyce
PREPARED BY:	C. Strickland	REVIEWED BY:	

REVISIONS	INIT.	DATE

SEAL

NORTH CAROLINA PROFESSIONAL SEAL 022013 ENGINEER GEORGE C. BROWN

DocuSigned by: George C. Brown 9/5/2014
E29D1EF0BEB4A4
DATE

SIG. INVENTORY NO. 05-0740

05-SEP-2014 07:31
S:*TISS&SM*TS Signals*Workgroups*Sig Mon*Strickland*050740_sm_ele_xxx.dgn
castrickland