

PROJ. REFERENCE NO.	SHEET NO.
DF18314.2045060	TMP-1C

301 FAYETTEVILLE STREET
SUITE 1500
RALEIGH, NC 27601
(919) 882-7839
NC FIRM LICENSE: C-1506

PHASING NOTES

THE CONTRACTOR IS RESPONSIBLE FOR ENSURING ONLY ONE SITE IS CLOSED AT A TIME DURING CONSTRUCTION. THE IMMEDIATE CLOSURE OF A SITE SHOULD BE DONE USING RSD 1101.01 (SHEET 3 OF 3) AND RSD 1101.03 (SHEET 1 OF 9). ONCE ONE SITE IS COMPLETE, THE CONTRACTOR SHALL MOVE THE APPROPRIATE CLOSURE SIGNAGE TO THE NEXT AVAILABLE SITE.

SITE 3 MUST BE CONSTRUCTED FIRST AND SITE 8 MUST BE CONSTRUCTED LAST. ALL OTHER SITES MAY BE COMPLETED IN ANY ORDER, BUT THE CONTRACTOR SHALL COORDINATE WITH THE ENGINEER FOR APPROVAL OF SEQUENCING PRIOR TO MOVING CLOSURE SIGNAGE.

PHASE 1:

STEP 1: PRIOR TO ANY CONSTRUCTION OPERATIONS, PLACE AND COVER OFFSITE DETOUR SIGNS AND DEVICES FOR SR 1602 (GILLIAM MOUNTAIN RD) AND SR 1602 (SUGAR LOAF MOUNTAIN RD), AS SHOWN ON TMP-3 AND TMP-4. PLACE ADVANCE WARNING SIGNS PER RSD 1101.01 (SHEET 3 OF 3).

STEP 2: USING THE OFFSITE DETOUR, SHOWN ON TMP-3 AND TMP-4, UNCOVER DETOUR SIGNS, CLOSE -L- SR 1710 (BALD ROCK RD) TO TRAFFIC AND CONSTRUCT PROPOSED ROADWAY, DRAINAGE, AND GEOTECHNICAL UP TO AND INCLUDING THE FINAL LAYER OF SURFACE COURSE PER THE ROADWAY PLANS.

PHASE 2:

STEP 1: REPEAT PHASE 1 UNTIL ALL SITES ARE COMPLETE EXCEPT SITE 8. WHEN WORKING ON SITES 10 AND 11 USE RSD 1101.03 SHEETS 1 AND 2 OF 9.

STEP 2: UPON COMPLETION OF ROADWAY CONSTRUCTON ON ALL SITES, PLACE FINAL PAVEMENT MARKINGS AND MARKERS PER PAVEMENT MARKING PLANS. REMOVE ALL SIGNS AND DEVICES AND OPEN -L- SR 1710 (BALD ROCK RD) TO TRAFFIC.

PHASE 3:

STEP 1: PRIOR TO ANY CONSTRUCTION OPERATIONS ON SITE 8, PLACE AND COVER OFFSITE DETOUR SIGNS AND DEVICES FOR SR 1712 (LEDBETTER RD), SR 1710 (BALD ROCK RD), AND SR 1602 (SUGAR LOAF MOUNTAIN RD), AS SHOWN ON TMP-5 AND TMP-6. PLACE ADVANCE WARNING SIGNS PER RSD 1101.01 (SHEET 3 OF 3).

STEP 2: USING THE OFFSITE DETOUR, SHOWN ON TMP-5 AND TMP-6, UNCOVER DETOUR SIGNS, CLOSE -Y1- SR 1712 (LEDBETTER RD) TO TRAFFIC AND CONSTRUCT PROPOSED ROADWAY, DRAINAGE, AND GEOTECHNICAL UP TO AND INCLUDING THE FINAL LAYER OF SURFACE COURSE PER THE ROADWAY PLANS. USE RSD 1101.02 SHEET 1 OF 19 AS NEEDED FOR THE TIE-IN WORK WITH SR 1710 (BALD ROCK RD).

STEP 3: UPON COMPLETION OF ROADWAY CONSTRUCTON, PLACE FINAL PAVEMENT MARKINGS AND MARKERS PER PAVEMENT MARKING PLANS. REMOVE ALL SIGNS AND DEVICES AND OPEN -Y1- SR 1712 (LEDBETTER RD) TO TRAFFIC.

<div>APPROVED: <div>Signed by: <i>Jacob H. Duke</i> 29530C0054E94D9.</div></div> <div>DATE: 7/29/2025</div> <div>SEAL</div> <div></div> <div>DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED</div>	<div></div>	<div>PHASING NOTES</div>
---	--	--------------------------