

BEGINNING AND END OF CONCRETE PAVEMENT:

(7-1-95)

710

SP7 R15

Install dowels in the concrete pavement at its beginning and ending to allow for future tie-in of concrete pavement in accordance with the detail in the plans and as directed by the Engineer.

No direct payment will be made for this work as such work will be included in the cost of the concrete pavement being constructed.