

CLEARING AND GRUBBING – METHOD III:

(4-6-06) (Rev 3-18-08)

SP2 R02

Perform clearing on this project to the limits established by Method “III” shown on Standard No. 200.03 of the *2006 Roadway Standard Drawings*.

Revise the *2006 Standard Specifications* as follows:

Page 2-2, Article 200-3, Clearing, add the following as the 6th paragraph:

At bridge sites, clear the entire width of the right of way beginning at a station 3 feet back of the beginning extremity of the structure and ending at a station 3 feet beyond the ending extremity of the structure.