

**PAVING INTERSECTIONS, DRIVEWAYS, AND MAILBOX TURNOUTS:**

(7-1-95)

R6 R70

Surface all unpaved intersections back from the edge of the pavement on the main line of the project at least 50 feet. Surface all driveway and mailbox turnouts as directed by the Engineer. The pavement placed in the intersections shall be of the same material and thickness as being used on the main line. Use material to pave driveway and mailbox turnouts that are being used on the project and place it in depths directed by the Engineer.

Resurface all paved intersections back to the ends of the radii, or as directed by the Engineer.

The unpaved intersections, driveways, and mailbox turnouts will be prepared for surfacing by State Forces.

Widen the pavement on curves as directed by the Engineer.