

16_19 Light Texts in the XPL File (Models)

Question:

The side elevation texts and the station texts on the XPL sheets are light. Weight is set to zero. What can I do to fix this?

Answer:

A compiled Microstation Basic program called "RD_FixLightXplTexts.ba" has been placed in the Roadway workspace to fix light texts in the XPL file. To process all the models in a XPL file, Roadway Designers will need to execute the Microstation Command file "RD_FixLightXplTexts.txt" in Batch Process mode. Batch Process mode can be called up via the Microstation menu, under "Utilities". Make a copy of the original XPL file before running this program.

A video tutorial is in the plan to further explain how to run this program.

Location:

RD_FixLightXplTexts.ba - C:\NCDOT_V8_WORKSPACE\Roadway_STDS\Standards\macros

RD_FixLightXplTexts.txt - C:\NCDOT_V8_WORKSPACE\Roadway_STDS\Standards\appl