


## 1\_5 BRIDGE GUARDRAIL NOT SHOWING

**Question:**

The guardrail for bridge warrant is not being read correctly on the right side approaching the bridge.

**Answer:**

Sometime when the EOP graphics and the GR graphics are top of each other, the GR graphics are not processed.



You can move the GR graphics just a hair (0.1') outside of EOP to fix this.