


5_2 PAVEMENT LAYERS IN THE XPL FILE

Question:

Why are the driveways and pavement surfaces not plotted? Also are the pavement layers shown in the XPL?

Answer:

Some corridor modeling cross section levels are turned off for plotting in the levels DGNLIB. These two were turned off by mistake. This issue has been fixed.



Pavement layers are needed in the XSC to extract their quantities. Showing pavement layers in the XPL is **optional**. If you wish not to show pavement layers in the XPL, turn those levels off in the XSC before creating the cross section sheets. The pavement layers are then turned off in the XPL before plotting.

