

I need to change a Conversion Factor on my CBOM but it is grayed out. Who can change Conversion Factors on the Contract BOM?

With the release of HiCAMS Version 8.1 on November 19, 2010, a new Security permission was implemented so that only specified users would be able to modify a conversion factor that had been defaulted from the Master Bill of Materials (MBOM).

This means that if the conversion factor for a substitutable material was changed prior to the release and it needs to be updated, the user has no way to make the update.

Who can help?

Security to change the Conversion Factor has been granted to the following people:

- Area Materials Engineers
- Section Materials Specialists

In addition, the following M&T staff can make changes to the conversion factor:

- Francine Ward
- Randy Pace

For additional information about this topic, please contact Randy Pace or Francine Ward at 919-329-4200.

Reviewed 21 November 2014