HiCAMS User Guide

Chapter 2: Contract Maintenance

Section 3C:

Working with Concrete and Concrete Classes

<u>Contents</u> About Concrete and Concrete Classes Working with Concrete and Concrete Classes Determining the Concrete Class Required for a Material Adding a Material to the Contract Bill of Materials

> Copyright 2013 - NC Department of Transportation - Division of Highways Document Version 1.1 - HiCAMS Version 6.4 Revised October 2013

About Concrete and Concrete Classes

New functionality in HiCAMS Version 6.4 now checks to be sure that the concrete class of the Material being entered on a Sample, Field Inspection Report (FIR), or Material Receipt Report (MRR) matches the Concrete Class of the Concrete Mix Design being entered.

This insures that the correct specifications for the Material are used for reference.

What this means for the user is that Concrete Mix Designs that were previously able to be selected for use may no longer be available until changes are made to the Contract Bill of Material (CBOM) for the contract.

The HiCAMS modules impacted by this change are:

CONTRACT TRACKING - Review Material Receipts

FIELD INSPECTION REPORTS

- Precast Concrete
- Prestressed Concrete
- Review Concrete Pavement

SAMPLING

- Enter Sample Details

Working with Concrete and Concrete Classes

As an example, a user has been asked to enter a concrete sample for Contract C201550, Line item 71 "1'-6" Concrete Curb and Gutter". The concrete used is Class B. The mix design on the sample is 469MVFP27BE.

After entering the basic information on the sample, it is time to enter the Concrete Mix Design. The user enters the plant id (RM469) on the Prod/Supp tab of the sample, and clicks on the Concrete Mix Design selection icon. The window opens and looks like this:

😽 Hicams - [hicamsval]							_ 8 ×
File Edit Fur	ctions Inquiries References	<u>A</u> dmin <u>T</u> ools	Window <u>H</u> elp					
- C M	M ? 🚴 🎾 🖉 🖉							
Se Review Se	ample Details - Sample (Un	titled)						- 🗆 ×
*Sam	😓 Select a Concrete Mix D	esign					×	
	Mix Desig	n ID:		Sta	itus: (All)	-	Retrieve	
Mat	Producer's Mi	ix ID:		Metric/Eng	lish: Both	▼		
Cananal	Class of Cond	rete: Class B				•	Reset	
General	Air-Ent.	and CAID						
	Vibration St	atus: 100						
+4	Pozzolan 1	ype: (All)				▼		
	Concrete Fac	; ility: S & W F	Ready Mix Con	crete Co., □□S&W	Ready Mix C	oncrete - Southport - RM469]	
	Con	tract: C201550)	Plant ID	:			
		1	Deedweer's	Class of	Motrial			
	Mix Design ID	Expiration	Mix ID	Concrete	English	Concrete Facility	Plant ID	
	469BNFP27BNVE	12/31/2075	P27BN∨	Class B	English	S & W Ready Mix Concrete Co S Ready Mix Concrete - Southport Sc NC	&W RM469 outhport	
			_	<u>0</u> K	<u>C</u>	ancel		
Forw	ard	<u>V</u> oid	Au	thorize	Auto <u>G</u> e	nerate Test Format	s Test Results	
								_
Ready								

Notice that the class of concrete is now set to Class B. Previously, all concrete mix designs assigned to the contract from that plant were displayed. Before the correct Concrete Mix Design will appear, changes will need to be made to the Contract Bill of Materials.

Note: It is not necessary to lose the data already entered on the Sample. In this case, just cancel the Select a Concrete Mix Design window and then determine the Class of Concrete assigned to the mix design on the Sample. Once the material has been added to the CBOM, it can be changed on the Sample, and data entry can continue.

Determining the Concrete Class Required for a Material

If you find that you are unable to enter your MRR, Sample, or FIR for a concrete material, follow these steps:

Step 1: Go to References > Concrete Mix Designs > Review Mixes.

- **Step 2:** Enter your Contract Number and click Retrieve. All of the Concrete Mix Designs assigned to your contract will be displayed.
- Step 3: Find the Mix Design ID for the mix you are trying to use. Now look in the column labeled "Class of Concrete". This is the class of concrete that must be assigned to the material on the contract's CBOM in order for the Mix Design to be used.

e Edit Fyr	nctions Inquiries <u>R</u> eference	s <u>A</u> dmin <u>T</u> ools	<u>W</u> indow <u>H</u> elp		_						
- 6 1	8 👗 🎽 🖉 🛤 🕱										
Concrete	Mix Design						_				
	😓 Select a Concrete Mix Design										
	Mix Desi	gn ID:		State	is: (All)	_	Retrieve				
	Producer's N	lix ID:		Metric/Englis							
	Class of Con	crete: (All)			R <u>e</u> set						
ieneral	Air-Ent										
	Vibration S Pozzolan										
	Conorata Ea	oilita									
	Concrete Fa			Dia 10							
		itract: [C20155	u 🛄	Plant ID:		Ē					
	Mix Design ID	Expiration	Producer's Mix ID	Class of Concrete	Metric/ English	Concrete Facility	▲ Plant ID				
	469DYFP27AADSE	12/31/2075	P27AADS	Drilled Shaft	English	S & W Ready Mix Concrete Co S&W Ready Mix Concrete - Southport Southport NC	RM469				
	469DYFP27DSCNIE	12/31/2075	P27DSCNI	Drilled Shaft	English	S & W Ready Mix Concrete Co S&W Ready Mix Concrete - Southport Southport NC	RM469				
	469MVFP27BVE	12/31/2075	P27BV	Class B, Curb & Gutter Machine	English	S & W Ready Mix Concrete Co S&W Ready Mix Concrete - Southport Southport NC	RM469				
	469RVFP27AABRE	12/31/2075	P27AABR	Class AA, Slip-form Barrier Rail	English	S & W Ready Mix Concrete Co S&W Ready Mix Concrete - Southport Southport NC	RM469				
	 						▼				
				<u>0</u> K	C	ancel					

In this example, the Class of Concrete assigned to this mix design is Class B, Curb and Gutter Machine. This concrete class must be assigned to the material on the Contract Bill of Materials before the mix design can be used on the sample.

Adding the Material to the Contract Bill of Materials

Note: For complete information on working with the Contract Bill of Materials for your contract, please refer to the User Guide "Review Contract BOM" on the HiCAMS home page.

- Step 1: Open the Contract Bill of Materials for the project and select the Line Item to which materials need to be added, in this case, Line Item 71. Click the Insert button. The Material Selection window opens.
- **Step 2:** For the Material Type, select Concrete, Class B from the drop down list, and click Retrieve. The Material Selection window opens.

÷. Ei	HICAMS - [hicamsval] le Edit Fynclions Inquiries References Admi I A A A A A A A A A A A A A A A A A A A	n <u>T</u> ools <u>W</u> ind 1 2 /12 1x12 "iw1	ow <u>H</u> elp			_	_		_		
Filter: Material Type Contract Material Type Group: (All) Material Type: Concrete, Class B Material: Material:					Unit of Measure: [All) 6/19/2007	To:	▼	17	<u>R</u> etriev	ve t
	Material	UOM	Group		Material Type	Version	Metric/ English	MSG Status	From Date	To Date	
	Concrete, Class B Concrete, Class B, Curb and Gutter Mach	Cubic Yards Cubic Yards	Concrete Concrete	Concrete Concrete	, Class B , Class B	4.00	English English	Current Current	01/01/1999 01/01/1999	12/31/2075 12/31/2075	
				<u>о</u> к	<u>C</u> ancel						
1											

Step 3: Select the Material that has the correct concrete class from the list and click OK. Enter the conversion factor and Save.

Completing the Sample Entry

Return to the Review Sample Details window and change the material selected for the Sample.

To change the Material selected, click on the material selection icon \triangle . Change the line item to the sample line item and Retrieve. This is how the Material Selection window looks now that the material has been added to the Contract BOM:

🐨 HiCAMS - [hicamsval]							_ 5	×
Ele Edit Functions Inquiries References Admin Iools	s <u>W</u> indow <u>H</u> elp							
🐼 Material Selection								Z
Filter: O Material Type O Contract							Betrieve	٦ĺ
Material Type Group: (All)		-		Cont	ract: C201550		Louisto	1
Material Type: Concrete, Class B				Line I	tem: 1'-6"CONC CURB & GUTTER V		R <u>e</u> set	1
Material:			避 Unit	t of Meas	sure: (All)			1
Metric/English: (All)		-		From [Date: 01/15/2008 To: 01/15/20	18		
		Line	Contract	Work		CBOM MSG	CBOM MSG	-
Material	UOM	Item	Mod	ltem	Material Type	From Date	To Date	
Concrete, Class B	Cubic Yards	71			Concrete, Class B	06/19/2007	12/31/20/5	
Concrete, Class B, Curb and Gutter Machine	Cubic Yards	71			Concrete, Class B	06/19/2007	12/31/20/5	9
			.	0	. 1			
				Canc	ei			
·								
, ,								_

Select Concrete, Class B, Curb and Gutter Machine and click OK.

Click on the Concrete Mix Design selection icon and when it opens, the Class of Concrete is now set to Concrete, Class B, Curb and Gutter Machine, and the Mix Design on the sample card is now available.

😽 HiCAMS - [[hicamsval]							_ 8 ×				
File Edit Fur	nctions Inquiries <u>R</u> eferences	Admin Tools	Window <u>H</u> elp									
	1 899 ¥ 🔉 A2 / 22 A	5 . 5										
*Review S	sample Decails - Sample (Un	esign					×					
Sam	Mix Desig	n ID:		Stat	us: (All)	T						
Mat	Producer's Mi	ix ID:		Metric/Engli	sh: Both		Retrieve					
	Class of Conc	rate: Class E	Curb & Gutta	r Machina			Beset					
General	Air-Ent. and Vibration Status: (All)											
+4	Pozzolan 1	(All)				_						
	Concrete Fac	; ility: S&WF	Ready Mix Con	crete Co., DDS&W R	leady Mix C	oncrete - Southport - RM469						
	Con	tract: C201550)	Plant ID:								
			Producer's	Class of	Metric/							
	Mix Design ID	Expiration	Mix ID	Concrete	English	Concrete Facility	Plant ID					
	469MVEP27BVE	12/31/20/5	P278V	Class B, Curb & Gutter Machine	English	S & W Ready Mix Concrete Co S&W Ready Mix Concrete - Southport Southport	RM469					
						NC						
	,			or 1								
				UK	<u> </u>	ancel						
Form	vord .	Void		thorizo	Auto Cr	Toot Formate	Toot Poo	ulto				
		<u>.</u> 010	Au	uron <u>z</u> e	Auto Ge	restroimats	Test Res	uTra				
Ready												

Continue filling out the sample card information and Save the Sample.

If a previously used Concrete Mix Design is no longer available for use on a Material Receipt Report or Field Inspection Report, follow the same process to update the Contract Bill of Materials with the correct material.

Remember

- 1. Two of the materials impacted by this change were Class B Concrete for Curb and Gutter Machine and Class AA concrete for Slip Form Barriers. These materials will need to be added to the CBOM on existing contracts in order to enter Samples correctly. The materials have been added to the Master Bill of Materials so contracts going forward will have both materials.
- 2. If a higher class of concrete was used in place of the required class, the concrete is still tested against the specifications for the actual, higher class of concrete. The Engineer is allowed to accept the material if it meets the requirements for the lesser class.