



#9 BAR IN BOTTOM EACH END OF CAP

NOTE TO DETAILER:

DETAIL SHOWN IS FOR SINGLE ROW OF PILES.

END OF CAP DETAIL FOR INTERIOR PILE BENTS





#29 BAR IN BOTTOM EACH END OF CAP

NOTE TO DETAILER:

DETAIL SHOWN IS FOR SINGLE ROW OF PILES.

END OF CAP DETAIL FOR INTERIOR PILE BENTS