PROJ. REFERENCE NO.	SHEET NO.
W-5601BA	TMP-2

MANAGEMENT STRATEGIES

– US 220 BUSINESS TRAFFIC WILL BE MAINTAINED THROUGH LANE CLOSURES DURING NIGHT TIME HOURS

PHASING

STEP 1:
INSTALL WORK ZONE ADVANCE WARNING SIGNS IN ACCORDANCE WITH NCDOT ROADWAY STANDARD DRAWING NO. 1101.01. WHEN NO WORK IS BEING CONDUCTED FOR A PERIOD LONGER THAN ONE WEEK, REMOVE OR COVER ALL ADVANCE WORK ZONE SIGNS, AS DIRECTED BY THE ENGINEER.

STEP 2:

USING NCDOT STANDARD DRAWING NO. 1101.02 (SHEET 1 OF 15), BEGIN MILLING AND RESURFACING FROM –L– 10+20 TO –L–STA. 79+78 UP TO AND INCLUDING THE FINAL LAYER OF SURFACE COURSE AND MARKINGS.

STEP 3:

REMOVE ALL WORK ZONE TRAFFIC CONTROL DEVICES AND OPEN US 220 BUSINESS (–L–) TO FINAL TRAFFIC PATTERN.

DocuSigned by:
APPROVED: Greg S Davis 33D47B5F07BF4A8 DATE: 10/20/2017

SEAL

TEMPORARY TRAFFIC CONTROL PHASING

20-OCT-2017 13:53
Z:\rdy\randolph\W-5601BA_FayetteVilleSt\psh\tmp\W-5601BA_tmp.dgn
gsdavis AT DIV8-304810