ASPHALT PAVEMENTS - WARM MIX ASPHALT SUPERPAVE (Required):

(02-15-11) (Rev. 1-17-12) 610 SP6 R02

The use of Warm Mix Asphalt (WMA) is required on this project.