Profile Generator - Preferences



Adjustment Increments: These values are used by the PI Editing Tools. I.E. When you click on the '+' button beside the PI elevation, the PI is raised by 0.03.

Toggles: These toggles affect the different elements of the Profile Graph.

Symbology This can used to set the style, weight and color of the elements shown in the Profile Graph, including profile tangents, parabolics and control elevations.

Alerts-Warnings: This toggles on/off warning messages such as "Are you sure you want to delete this PI?"