Cross Sections Dialog



The Cross Section dialog serves three functions relating to cross section stations in the NCWedge project file:

- Loading (and Reloading) Existing Pavement Cross Sections
- Deleting Cross Sections
- Editing Cross Sections