	STUDENT NAME (Print)	Last Four digits SS			
	Checklist Chase Indicator AASHTO T-19	9-00 (NCDOT N	Modified)		
		TRIALS		RETRIAL	1
		1st	2nd	,	
1.	Fill brass cup with mortar. Do not consolidate				7
	during filling. Exclude particles of sand which	Pass	Pass		Pass
	would be retained on a 2.00 mm (No. 10) sieve.	Fail	Fail		Fail
2.	od the mortar in the cup using a thin stiff wire (No. 1 GEM paper clip). Detected during rodding, exclude particles of sand				
	which would be retained on a 2.00 mm	Pass	Pass		Pass
	(No. 10) sieve. Consolidate by tapping the side.	Fail	Fail		Fail
					•
3.	Strike off mortar flush with top or the cup.	Pass	Pass		Pass
0.	Carrie on mortal mass man top or the cap.	Fail	Fail		Fail
					_
4.	Insert cup into glass tube and add alcohol to the "0"				_
	reference on the stem. Make sure the bottom of	Pass	Pass		Pass
	the meniscus is in line with the "0" reference line.	Fail	Fail		Fail
5.	Be careful not to change setting of the stopper.	Pass	Pass		Pass
		Fail	Fail		Fail
					_
6.	Roll and tap the indicator until all mortar is				-
	dispersed in the alcohol and no more bubbles	Pass	Pass		Pass
	appear.	Fail	Fail		Fail
7.	Read and record the stem reading to the nearest ¼%.	Pass	Pass		Pass
	-	Fail	Fail		Fail
					_
8.	Calculate the air content to the nearest 0.1%	Pass	Pass		Pass
		Fail	Fail		Fail
				Г	1_
	Overall	Pass	Pass		Pass
		Fail	Fail		Fail
	ify that I have not helped, coached, or any way interference for any way interference examination.	red with the ex	kaminee dur	ing	

Date

Examiner

Name