

## PHASING

### STEP 1

INSTALL OFFSITE DETOUR SIGNS AND ROAD CLOSURE SIGNING AS SHOWN ON TMP-2 NO MORE THAN 3 DAYS PRIOR TO ROAD CLOSURE. IF ROAD IS NOT CLOSED WITHIN THE SAME WORKING PERIOD AS SIGN INSTALLATION, COVER ALL SIGNING.

### STEP 2


UNCOVER SIGNING. THEN USING TMP-02 DETOUR TRAFFIC OFFSITE AND CLOSE -L- (SR 1001 WARRENTON RD). BEHIND ROAD CLOSURE, CONSTRUCT -L- UP TO BUT NOT INCLUDING THE FINAL LIFT OF SURFACE COURSE.

### STEP 3


PLACE THE FINAL LIFT OF SURFACE COURSE, PAVEMENT MARKINGS, AND MARKERS (SEE PAVEMENT MARKING PLAN).

### STEP 4

REMOVE ALL TRAFFIC CONTROL DEVICES, ROAD CLOSURE SIGNING, AND OPEN -L- TO TRAFFIC. REMOVE ALL OFFSITE DETOUR SIGNING.




A




M4-8  
24" X 12"  
M6-1 R  
21" X 15"

B



M4-8  
24" X 12"  
M6-1 L  
21" X 15"


C



D




E



M4-8  
24" X 12"  
M6-3  
21" X 15"

F



G



H



W20-3  
48" X 48"  
SP-4L  
42" X 12"

I




J




SP-4R  
42" X 12"



L



K



TYPE III BARRICADE



OFFSITE DETOUR  
AND PHASING