




- NOTES:**
1. STEPS TO BE SHORT, FREQUENT, AND CLOSELY SPACED.
 2. POOL SPACING SHALL BE INVERSELY PROPORTIONAL TO STREAM SLOPE, AND DIRECTLY PROPORTIONAL TO BANKFULL WIDTH.
 3. POOL DEPTHS AT BANKFULL ELEVATION SHALL BE TYPICALLY 2 TO 3 TIMES DEEPER THAN STEP DEPTHS AT BANKFULL ELEVATION.
 4. ADEQUATE NUMBER OF FOOTER BOULDERS TO BE USED IN ORDER TO HOLD UP THE BOULDERS AT HEAD OF STEPS DURING HIGH ENERGY/HIGH FLOW EVENTS.
 5. STEP POOL DEPTH SHOULD BE 2 TO 3 TIMES BANKFULL DEPTH.



STATION	BOULDER DIMENSIONS (FT)		
	HEIGHT	LENGTH	WIDTH

ROCK CROSS VANE DETAIL FOR STEP POOLS
NOT TO SCALE

- NOTES:**
1. DEEPEST PART OF POOL TO BE IN LINE WITH WHERE VANE ARM TIES INTO BANKFULL.
 2. DO NOT EXCAVATE POOL TOO CLOSE TO FOOTER BOULDERS.
 3. CLASS "A" STONE CAN BE USED TO REDUCE VOIDS BETWEEN HEADERS AND FOOTERS.
 4. COMPACT BACKFILL TO EXTENT POSSIBLE OR AT THE DIRECTION OF THE ENGINEER.
 5. POOL DEPTH SHOULD BE 2 TO 3 TIMES BANKFULL DEPTH.