



FIGURE 6 - 38



IDEAL POUR - 2 SPANS

KEY




= INDICATES POUR NUMBER AND DIRECTION OF POUR

L = LENGTH OF EXTERIOR SPAN

n = RATIO OF $\frac{\text{INTERIOR SPAN}}{\text{EXTERIOR SPAN}}$


CJ = CONSTRUCTION JOINT
(SEE DESIGN MANUAL SECTION 6.2.2.8)

* = IF THE CONTRACTOR CHOOSES TO REVERSE THE DIRECTION OF POUR #1 A CONSTRUCTION JOINT (CJ) WILL BE REQUIRED 4'-0" FROM THE JOINT SEAL.



IDEAL POUR - 3 SPANS


FIGURE 6 - 38 M



IDEAL POUR - 2 SPANS

KEY

- ← ⊕ = INDICATES POUR NUMBER AND DIRECTION OF POUR
- L = LENGTH OF EXTERIOR SPAN
- n = RATIO OF $\frac{\text{INTERIOR SPAN}}{\text{EXTERIOR SPAN}}$
- CJ = CONSTRUCTION JOINT (SEE DESIGN MANUAL SECTION 6.2.2.8)
- * = IF THE CONTRACTOR CHOOSES TO REVERSE THE DIRECTION OF POUR #1 A CONSTRUCTION JOINT (CJ) WILL BE REQUIRED 1.220m FROM THE JOINT SEAL.



IDEAL POUR - 3 SPANS

WISCONSIN DOT POURING SEQUENCE