


NCDOT's Compliance Documentation Workflow for Rule 15A NCAC 04B .0109 *



* Refer to GUIDELINES FOR DRAINAGE STUDIES AND HYDRAULIC DESIGN section 10.5.3 Storm Drain System Outlet Analysis for more information. Document compliance in the project's Stormwater Management Plan (SMP). Note that there are no rules of thumb related to pre/post peak flow percent increase which serves as a substitute for compliance with the 15A NCAC 04B .0109 rule.